

HORIZON[®] LED

Natural Daylight Task Lamp



GEMORO[®]
Products

The definitive source for lighting.

Item # 2257

INSTRUCTIONS FOR USE & SAFETY PRECAUTIONS

Congratulations on your purchase of the Horizon LED, the ultimate natural daylight task lamp from GemOro! It features amazing super bright, high-power, natural daylight LED's that have been shown to improve color acuity, productivity and health. The Horizon LED provides the best lighting for many applications, including: diamond color grading, jewelry display, stamp, coin and art collecting, executive desks, bedside tables, reading and more.

SPECIFICATIONS

Model: Horizon LED


Output Voltage: DC24V

Output Amperage: 240mA

Power: 8W

FEATURES

- 6,000K Full Spectrum Natural Daylight Illumination
- High-Power Long Life LED Technology
- Sleek, Modern Ergonomic Design
- Electronic Membrane Touch Sensor Power Switch
- Dimmable Light Intensity
- Flex-Arm & Swivel Provide Fully Adjustable Light Angle
- 100V-240V Multi-Voltage UL Listed Adapter
- USB Power Port for Recharging Smartphone's, iPod's, etc.
- Heavy Weighted Base



ASSEMBLY INSTRUCTIONS

1. Remove screw cap from lamp flex arm by turning it counter clockwise.



2. Insert screw cap in the hole from the bottom of the lamp base.



3. Insert threaded end of lamp arm into the top of the lamp base so that the threads align with the screw cap.



4. While holding the screw cap steady, turn the lamp arm clockwise while screwing it into the cap. A coin may be used for leverage while screwing the cap in.



OPERATING INSTRUCTIONS

1. Locate the DC socket on the backside on the lamps arm near where it attaches to the weighted base and insert the AC adapter plug.
2. Plug the other end of the AC adapter into a suitable wall power outlet.
3. Touch the chrome electronic membrane touch sensor power switch at the base of the arm to power the lamp on and off. To activate the dimming feature and adjust the light intensity, simply touch and continue pressing this switch down until the desired brightness level has been achieved.
4. Adjust lamp's flex arm to optimally position the light angle.
5. Locate the USB socket power port on the side of the lamps flex arm near where it attaches to the heavy weighted base and as needed plug in an appropriate USB power cord to charge Smartphone's, iPod's, etc.

WARRANTY

Your Horizon LED features a One Year Limited Warranty. The warranty period begins on the date that your Horizon LED is purchased, as noted on the bill of sale (if supplied) or through the Horizon LED serial number tracking system, as interpreted by the factory (the "Warranty Commencement Date"). The One Year Limited Warranty begins on the Warranty Commencement Date and expires 365 days thereafter (the "One Year Limited Warranty Period"). During the One Year Warranty Period, the Horizon LED is warranted against defects in materials and workmanship under normal and intended use as determined by the factory. No warranty, of any kind or character, exists after the expiration of the One Year Limited Warranty Period. If a defect exists, at its option GemOro will (1) repair the product at no charge, using new or refurbished replacement parts, (2) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product, (3) in the event the Horizon LED is no longer available or has been discontinued and warranty coverage is applicable, at the factory's sole discretion, a substantially equivalent task lamp may be substituted in place of the defective Horizon LED or (4) refund the purchase price of the product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes GemOro's property. If and when a refund is given, your product becomes GemOro's property. The purchaser shall incur the cost for return postage, insurance and handling for all warranty and non-warranty repairs.

GemOro Horizon LED
WARRANTY REGISTRATION
10455 Olympic Drive, Dallas, Texas 75220 USA
Tel 800.527.0719 or 214.351.0380
Fax 800.832.9871 or 214.351.1903
Website: www.gemoroproducts.com
Email: support@gemoroproducts.com
Warranty Registration:
www.gemoroproducts.com/warrantyregistration/

This warranty does not apply to: (a) damage caused by accident, abuse, misuse, misapplication, or non-GemOro products; (b) damage caused by service (including upgrades and expansions) performed by anyone who is not a GemOro authorized service provider; (c) a product or a part that has been modified without the written permission of GemOro; or (d) any GemOro product whose serial number has been removed or defaced.

THIS WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED. GEMORO SPECIFICALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IF GEMORO CANNOT LAWFULLY DISCLAIM IMPLIED WARRANTIES UNDER THIS LIMITED WARRANTY, ALL SUCH WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED IN DURATION TO THE DURATION OF THE ONE YEAR WARRANTY PERIOD. NO GEMORO RESELLER, AGENT, OR EMPLOYEE IS AUTHORIZED TO MAKE ANY MODIFICATION, EXTENSION, OR ADDITION TO THIS WARRANTY.

GEMORO IS NOT RESPONSIBLE FOR DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR CONDITION, OR UNDER ANY OTHER LEGAL THEORY, INCLUDING BUT NOT LIMITED TO LOST PROFITS, DOWNTIME, GOODWILL, AND DAMAGE TO OR REPLACEMENT OF EQUIPMENT AND PROPERTY.

GEMORO[®] Products

10455 Olympic Drive,
Dallas, Texas 75220 USA
Tel 800.527.0719 or 214.351.0380
Fax 800.832.9871 or 214.351.1903
www.gemoroproducts.com
support@gemoroproducts.com